


AUTOMATIC CHANGE/OVER THERMOSTAT

ME-52 MICRO-ELECTRONIC MULTISTAGE THERMOSTAT



NOTE: Thermostat requires (6) low voltage wires. The DH-46 de-humidistat will over ride the thermostat for appropriate humidity control.

- ME-52 is a microelectronic thermostat with (2) stage heating and (2) stage cooling.
- Automatic heat/cool change/over
- Auto: Normal setting for year round comfort. Setting for between seasons when thermostat selects cooling or heating as required.
- Fan setting options:
 - Auto: Normal setting for most applications. Equipment controls the fan.
 - On: The fan runs continuously. Use for improved air circulation and air quality.
- Digital display:
 - You can easily read the current room temperature at a glance.
- Backlit display:
 - Turns on with the touch of any key.